

Nazwa/seria modelu falownika	Model baterii	Rzeczywista pojemność, kWh
<a href="#">DEYE SUN-29.9/30/35K-SG01HP3-EU-BM3 SUN-40/50K-SG01HP3-EU-BM4</a>	Freen-BSH	9.9
<a href="#">DEYE SUN-5/6/8/10/12/15/20/25K-SG01HP3-EU-AM2</a>	Freen-BSH	9.9
<a href="#">DEYE SUN-60/70/75/80K-SG02HP3-EU-EM6</a>	Freen-BSH	9.9
<a href="#">Ferroamp Energyhub 14</a>	Freen-BSH	9.5
<a href="#">FoxEss H1(G2)/AC1(G2)</a>	Freen-BSH	10.1
<a href="#">FoxEss H3/AC3</a>	Freen-BSH	9.7
<a href="#">FoxEss KH/KA</a>	Freen-BSH	10.1
<a href="#">Fronius Primo GEN24 Plus</a>	Freen-BSH	10.0
<a href="#">Fronius Symo GEN24 Plus</a>	Freen-BSH	9.9
<a href="#">Fronius Verto Plus</a>	Freen-BSH	10.0
<a href="#">Goodwe EH PLUS+ Series</a>	Freen-BSH	10.1
<a href="#">Goodwe ET G2 Series</a>	Freen-BSH	10.0
<a href="#">Goodwe ET PLUS+ Series</a>	Freen-BSH	9.7
<a href="#">Goodwe ET Series</a>	Freen-BSH	9.3
<a href="#">Goodwe ET Series</a>	Freen-BSH	9.3
<a href="#">Growatt SPH 4000-10000TL3 BH-UP</a>	Freen-BSH	10.1
<a href="#">Growatt WIT 8-25K-XHU</a>	Freen-BSH	10.1
<a href="#">HOYMILES HAT-8.0HV-EUG1</a>	Freen-BSH	9.8
<a href="#">HOYMILES HYT-10.0HV-EUG1</a>	Freen-BSH	9.8
<a href="#">SMA Sunny Boy Smart Energy3.6 / 4.0 / 5.0 / 6.0</a>	Freen-BSH	10.1
<a href="#">SMA Sunny Boy Smart Energy-US 3.8 / 4.8 / 5.8 / 7.7 9.6 / 11.5</a>	Freen-BSH	10.1
<a href="#">SMA SUNNY BOY STORAGE 2.5</a>	Freen-BSH	10.1
<a href="#">SMA SUNNY BOY STORAGE 3.7 / 5.0 / 6.0</a>	Freen-BSH	10.1
<a href="#">SMA SUNNY BOY STORAGE 3.8-US / 5.0-US / 6.0-US</a>	Freen-BSH	10.1
<a href="#">SMA Sunny Island X30</a>	Freen-BSH	9.3
<a href="#">SMA Sunny Tripower Smart Energy 5.0 / 6.0 / 8.0 / 10.0</a>	Freen-BSH	10.0
<a href="#">SMA Sunny Tripower Storage X</a>	Freen-BSH	9.3
<a href="#">Sofar HYD 5K-20KTL-3PH</a>	Freen-BSH	9.7
<a href="#">SofarSolar HYD 5~20KTL-3PH</a>	Freen-BSH	9.7
<a href="#">Solax X1-AC</a>	Freen-BSH	10.1
<a href="#">Solax X1-FIT G4</a>	Freen-BSH	10.1
<a href="#">Solax X1-HYBRID G4</a>	Freen-BSH	10.1
<a href="#">Solax X1-SPT Series</a>	Freen-BSH	10.1
<a href="#">Solax X1-VAST</a>	Freen-BSH	10.1
<a href="#">Solax X3-AELIQ</a>	Freen-BSH	9.7
<a href="#">Solax X3-FIT G4</a>	Freen-BSH	10.1
<a href="#">Solax X3-HYB G4 PRO</a>	Freen-BSH	10.1
<a href="#">Solax X3-HYBRID G4</a>	Freen-BSH	10.1
<a href="#">Solax X3-ULTRA</a>	Freen-BSH	10.1
<a href="#">Solax X3-ULTRA</a>	Freen-BSH	10.1
<a href="#">Solis S6-EH1P(3.8-11.4)K-H-US</a>	Freen-BSH	10.1
<a href="#">Solis S6-EH3P(30-60)K-NV-YD-H-US(21A)</a>	Freen-BSH	10.0
<a href="#">Sungrow SH15/20/25T</a>	Freen-BSH	10.1
<a href="#">Sungrow SH3.0/3.6/4.0/5.0/6.0RS</a>	Freen-BSH	10.1
<a href="#">Sungrow SH5.0/6.0/8.0/10RT</a>	Freen-BSH	10.0
<a href="#">Sungrow SH5.0/6.0RS-20</a>	Freen-BSH	10.1
<a href="#">Sungrow SH5T/6T/8T/10T/12T/15T/20T/25T</a>	Freen-BSH	10.1
<a href="#">Sungrow SH8.0 - 10RS</a>	Freen-BSH	10.1
<a href="#">Sunways STH 15~33kW</a>	Freen-BSH	9.3
<a href="#">Sunways STH 3-8KTL-HS</a>	Freen-BSH	10.1
<a href="#">Sunways STH 4~12kW</a>	Freen-BSH	10.1

Nazwa/seria modelu falownika	Model baterii	Rzeczywista pojemność, kWh
<a href="#">DEYE SUN-12/14/16K-SG01LP1-EU</a>	Freen-BSL	7.7
<a href="#">DEYE SUN-14/15/16/18/20K-SG05LP3-EU-SM2</a>	Freen-BSL	7.7
<a href="#">DEYE SUN-3.6/5/6/7/7.6/8/10K-SG05LP1-EU</a>	Freen-BSL	7.7
<a href="#">DEYE SUN-3.6/5/6/7/7.6/8/10K-SG05LP1-EU-SM2-P</a>	Freen-BSL	7.7
<a href="#">DEYE SUN-3.6/5/6K-OG01LP1-EU-AM2</a>	Freen-BSL	7.7
<a href="#">DEYE SUN-3/4/5/6/8/10/12K-SG05LP3-EU-SM2</a>	Freen-BSL	7.7
<a href="#">DEYE SUN-3K-SG04LP1-24-EU SUN-3/3.6/5/6K-SG04LP1-EU</a>	Freen-BSL	7.7
<a href="#">DEYE SUN-3K-SG04LP1-24-EU-SM1 SUN-3K-SG04LP1-EU-SM1 SUN-3.6/5/6K-SG04LP1-EU-SM2</a>	Freen-BSL	7.7
<a href="#">DEYE SUN-5/6/7.6/8K-SG01LP1-US</a>	Freen-BSL	7.7
<a href="#">DEYE SUN-5/6/7.6/8K-SG02LP2-US-AM2 SUN-10/12K-SG02LP2-US-AM3</a>	Freen-BSL	7.7
<a href="#">DEYE SUN-5/6/8/10/12K-SG04LP3-EU</a>	Freen-BSL	7.7
<a href="#">DEYE SUN-7.6/8K-SG01LP1-EU</a>	Freen-BSL	7.7
<a href="#">Goodwe EM Series</a>	Freen-BSL	7.7
<a href="#">Goodwe ES G2 Series</a>	Freen-BSL	7.7
<a href="#">Goodwe ET LV Series</a>	Freen-BSL	7.7
<a href="#">Goodwe SBP G2 Series</a>	Freen-BSL	7.7
<a href="#">Growatt SPH 3000-6000TL-BL-UP</a>	Freen-BSL	6.8
<a href="#">Growatt SPM 3000-6000TL-HU</a>	Freen-BSL	7.7
<a href="#">Growatt WIT 4-15K-HU</a>	Freen-BSL	7.7
<a href="#">HOYMILES HAS-5.0LV-EUG1</a>	Freen-BSL	7.7
<a href="#">HOYMILES HIT-10L-G3</a>	Freen-BSL	7.7
<a href="#">HOYMILES HYS-6.0LV-EUG1</a>	Freen-BSL	7.7
<a href="#">Schneider Xantrex™ XW</a>	Freen-BSL	8.1
<a href="#">SMA Sunny Island</a>	Freen-BSL	7.9
<a href="#">SMA SUNNY ISLAND 6048-US</a>	Freen-BSL	7.9
<a href="#">Sofar HYD 3-6K-EP</a>	Freen-BSL	6.5
<a href="#">Sofar HYD-10K-LS1</a>	Freen-BSL	7.7
<a href="#">Sofar HYD-3-8K-LS1-PRO</a>	Freen-BSL	7.7
<a href="#">Sofar ME 3000SP</a>	Freen-BSL	6.5
<a href="#">SofarSolar HYD 3000~6000-EP</a>	Freen-BSL	6.5
<a href="#">SofarSolar HYD 3000-6000-ES</a>	Freen-BSL	6.5
<a href="#">SofarSolar ME 3000SP</a>	Freen-BSL	6.5
<a href="#">Solax X1-HYB-LV</a>	Freen-BSL	7.7
<a href="#">Solax X1-Lite-LV</a>	Freen-BSL	7.7
<a href="#">Solax X1-RENO-LV</a>	Freen-BSL	7.7
<a href="#">Solax X3-NEO-LV</a>	Freen-BSL	7.7
<a href="#">Solis S6-EH1P(3-8)K-L-PLUS</a>	Freen-BSL	7.7
<a href="#">Solis S6-EH2P(9.6-16)K03-SV-YD-L-US</a>	Freen-BSL	7.7
<a href="#">Studer AJ series</a>	Freen-BSL	8.5
<a href="#">Studer Next1</a>	Freen-BSL	8.5
<a href="#">Studer Next3</a>	Freen-BSL	8.5
<a href="#">Studer Variosting</a>	Freen-BSL	8.5
<a href="#">Studer Variotrack</a>	Freen-BSL	8.5
<a href="#">Studer Xtender</a>	Freen-BSL	8.5
<a href="#">Sungrow MG5RL/MG6RL</a>	Freen-BSL	7.7
<a href="#">Sunways STH-3-8KTL-LS</a>	Freen-BSL	7.7
<a href="#">Victron MultiPlus II 48/3000-15000</a>	Freen-BSL	8.5
<a href="#">Victron MultiPlus II 48/4k-6k</a>	Freen-BSL	8.1
<a href="#">Victron MultiPlus-II 120V</a>	Freen-BSL	8.5
<a href="#">Victron SmartSolar 250/100 MPPT TR VE</a>	Freen-BSL	9.5